

Overview UV measurement for UV lamps

1. UV Integrators

Picture Art. No.	Range	Val Peak mW/cm²	ue Dose mJ/cm²	Short description	
UV Disc A002400 (Full UV) A003371 (UV-C) A004346 (UV-B) A003909 (UV-A) A002915 (UV-Vis) A004192 (UV-LED)	Full UV UV-A UV-B UV-C UV-Vis UV-LED		✓	Type: Spectral measuring ranges: Measuring ranges: Display range: Display: Dimensions: Weight:	UV Disc Full UV: 250 – 410 nm (standard) or UV-A: 315 – 410 nm UV-B: 280 – 315 nm UV-C: 230 – 280 nm UV-VIS: 395 – 445 nm UV-LED: 265 – 495 nm (for UV-LEDs 320405 nm) 1 – 5,000 mW/cm² 1 – 10.000 mW/cm² (A004192) 1 – 999 999 mJ/cm² LCD 6 digits Ø 90mm, height 12 mm approx. 140 g
UV Micro Puck Multi Integrator A002197 (Handheld) UV-Sensoren: A002201 (UV full) A002198 (UV-C) A002199 (UV-B) A002200 (UV-A) A005156 (UV-Vis) A004094 (UV-LED)	Full UV UV-A UV-B UV-C UV-Vis UV-LED		√	Type: Spectral measuring range: Measuring ranges: Display range: Display: Dimensions: Weight:	UV Micro Puck Multi Integrator Full UV: 230 – 410 nm UV-A: 315 – 410 nm UV-B: 280 – 315 nm UV-C: 230 – 280 nm UV-VIS: 395 – 445 nm UV-LED: 265 – 495 nm (for UV-LEDs 320405 nm) 1 – 5.000 mW/cm² 0 – 2.000 mJ/cm2 0 – 20.000 mJ/cm2 (Faktor 10) LCD, 2x16 digits 40 mm x 14 mm x 12 mm ca. 30 g cable-less UV sensors, switchable sensitivity (10x)





continuation UV Integrators

Picture	Ranges	Val	ue	Short description	
Art. No.	rtungoo	Peak	Dose	Chort accomption	
		mW/cm²	mJ/cm ²		
DO General Control of the Control of	UV-A UV-B	✓	√	Туре:	UV Control 4C TFT (UV-A, -B, -C, -Vis)
	UV-C UV-Vis* UV-LED*				UV Control 4CT TFT (UV-A, -B, -C, -Vis, -Temp.)
un maderi al di	Temp.*				UV Control 4C LED TFT (UV-A, -B, -C, -Vis, LED)
UV Control 4C TFT A008418 UV Control 4CT				Spectral measuring ranges:	UV-A: 315 – 410 nm UV-B: 280 – 315 nm UV-C: 230 – 280 nm UV-Vis: 395 – 445 nm UV-LED*: 265 - 495 nm (4C LED)
TFT A008420 UV Control 4C LED TFT				Temperature: Measuring range: Recording cycle: Display:	0 – 110 °C (4CT) 1 – 2,000 mW/cm² 30400 s (selectable) TFT color display 40 x 31,5 mm
A008419				Dimensions: Weight:	140 x 65 x 12 mm approx. 230 g
				Special features:	The integrator has a SD card slot to save the data. On the built in display or with the included software the data can be displayed as graphs and the data can be stored on a computer. Scope of delivery: software, USB cable, SD card and plastic case.
A006649	SV Gradual			Option	WLAN functonality for UV Control Wireless file transfer from UV Control to smartphone or PC via Web App.
	Smartp	phone not inc	luded	example Web App	This Web App reads out and shows UV Controls measured values (mW/cm² / mJ/cm²) and displays the irradiance profile on smartphone or PC.
					Scope of delivery: FlashAir [™] SD card with installed Web App software. Note: The WLAN functionalty is device-related.



continuation UV Integrators

Photo Art. No.	Range	Va Peak	lue Dose	Short description	
AIT. NO.		mW/cm ²	mJ/cm ²		
		*	✓	Type:	UV Tube 3C UV Tube 3CT UV Tube 4C
UV Tube 3C A005097 UV Tube 3CT A005739 UV Tube 4C A007656				curing applications. It is d peak UV intensity, UV do in bottle/tube machines. The sensor has to be fixe dummy. The small size a	s UV multi-channel-measuring instrument for esigned to measure, record and display sage and temperature (UV Tube 3CT only) d during passage in a customer-side and extremely low weight of the UV Tube sunder realistic conditions.
	UV-A UV-B UV-C Temp.*			Spectral measuring ranges: Temperature: Measuring range: Recording cycle: Display: Dimensions: Weight: Special features:	UV-A: 315 – 410 nm UV-B: 280 – 315 nm UV-C: 230 – 280 nm UV-Vis: 395 – 445 nm (4C only) 0 – 110 °C* (3CT only) 1 – 2,000 mW/cm² 90 s ./. Ø 25 mm, L = 60 mm approx. 40 g / 55 g Very small multi-channel integrator with extremely low weight. The aluminium housing must be protected from strong UV light and heat, eg by a suitable support or light shield. Very high sampling rate. The device has a micro SD card slot for storage of all measured values. The reading of the measured values is done via USB cable. The included multifunctional software provides the measured values on the PC graphic. The measured values can be stored on the PC and exported to spreadsheet programs. Software, SD card and plastic box are included.



2. UV spectrometer

Photo	Ranges	Uı	nit	Short description	
Art. No.		Peak mW/cm ²	Dose mJ/cm ²		
UV Spectro	Spectro-	IIIVV/CIII-	IIIJ/CIII-	Туре:	UV Spectro
To long to sense to the sense t	meter 200 – 440 nm	✓	✓	pass-through unit. It can the quantitative and qualitative individual wavelengths. As the doses can also be calculated as the doses can also be calculated as the doses.	
A003667				functions can optionally be	n be freely selected, and weighting stored.
				Spectral range: Spectral bandwidth: Measurement range: Measurement range: Display range: Display: Dimensions: Weight: Calibration: Special feature:	200 – 440 nm 2 nm 2 – 5,000 mW/cm² (A003650) 25– 35,000 mW/cm² (A003667) 1 mJ/cm² – 600 J/cm² (A003650) 25 mJ/cm² – 4,200 J/cm² (A003667) LCD 6 digits 160 x 100, height 14.4 mm approx. 375 g Traceable to PTB Both UV medium-pressure lamps and UV LEDs can be measured within the spectral range. One or more effect-related weighting functions or sensitivity curves can be stored.
or reaches 415° or reaches 415	Spectro- meter 200 – 440 nm with USB interface	√	✓	Type: Measurement range: Measurement range: Special feature:	UV Spectro USB ditto but with USB interface 2 – 5.000 mW/cm² (A004452) 25 – 35.000 mW/cm² (A004453) 50 measurements can be recorded, edited and exported via USB (the software is inclusive).
A004452				Spectrum:	Irradiance profile:
A004453					
				Irradiances as bar charts:	Doses as bar charts:
				September 1	



3. UV intensity measurement for short time measuring

Picture	Range	Val	lue	Short description	
Art. No.	90	Peak mW/cm²	Dose mJ/cm		
THE COLUMN TO STATE OF					nt display with units asured value, mum values, hold function onitoring, sensor breakage indication,
HI 1 handheld A002067				Dimemsions / weight Special features HI 1:	approx. 125x80x40 mm / 270 g One handheld for different sensors, saving of max. and min. values, hold function
A002069 A002071 A002073 A002673 A002906	UV-A or UV-B or UV-C or UV-VIS or UV LED	* * * *		Type: Spectral measuring ranges:	SI 1 sensor 315 – 395 nm, max. 340 nm 265 – 325 nm, max. 315 nm 215 – 280 nm, max. 265 nm 395 – 445 nm, max. 435 nm 320 – 395 nm, max. 350 nm
UV sensor SI 1				Max. intensity: Dimensions / weight Special features SI 1:	2,000 mW/cm² for max. 30 s for UV-LED: 20 W/cm² (max. 5 s) Ø 36 mm, height 17 mm / 70 g Calibration saved in the sensor plug, available for different spectral ranges and intensities.
A004574 A004573 A004572 A004575 A004576 A005030	UV-A or UV-B or UV-C or UV-VIS or UV-full UV-LED	* * * * * *		Type: Spectral measuring ranges: Max. intensity: Dimensions / weight Stainless steel tube: Special features TS 1:	TS 1 315 – 395 nm, max. 340 nm 265 – 325 nm, max. 315 nm 215 – 280 nm, max. 265 nm 395 – 445 nm, max. 435 nm 230 – 410 nm, max. 330 nm 265 – 495 nm, max. 350 nm 10.000 mW/cm² for max. 5 s Total length: 440 mm, plunge depth with mounting and guidance plate: 230 mm Ø 6 mm Calibration saved in the sensor plug, available for different spectral
UV sensor TS 1					ranges.



Note: Also the IR sensor PMI 41 for measuring the quartz glass temperature of UV curing lamps can be connected to the handheld HI 1. For more information, kindly notice our IR sensor data sheet.





4. Online UV intensity measurement for permanent measuring

Picture	Range	Val	ue	Short description	
Art. No.		Peak	Dose		
		mW/cm²	mJ/cm		
				Type:	QSO 3
QSO 3				curing applications. It emits the measured UV radiation The photodiode is located UV radiation incident on the total reflection in the quartz	continuous intense UV irradiation at UV as a sensor signal that is proportional to in the form of a DC 010 V signal. Dutside the actual radiation zone. The equartz glass window is damped by a glass rod and thus reaches the extemperature load of the photodiode is
				ageing, or they use the ser machine controller. The pu	ensor in order to detect the lamp asor signal to control the ballast via a rpose is to realise constant ne electrical power of the lamp.
UV-A: A002179 UV-B: A002178 UV-C: A002177	UV-A or UV-B or UV-C	by DC 0 – 10V		Spectral measuring ranges: Sensitivity range: Amplification factor: Max. permissible intensity: Max. permissible temp.: Supply: Output: Dim./weight sensor box: Stainless steel tube: Special feature:	315 – 395 nm, max. 340 nm 265 – 325 nm, max. 315 nm 215 – 280 nm, max. 265 nm 20 – 2.000 mW/cm² 1, 10, 100, 1000; x 0,3 10.000 mW/cm² for max. 10 min ~ 300° C quartz rod window External by DC 24V, 5mA DC 0-10V, proportional to UV Approx. 45 x 45 x 34 mm / 200 g Ø 8 mm Air purging connection 1/8"



continuation Online UV intensity measurement for permanent measuring

Picture	Range	Value		Short description	
Art. No.		Peak mW/cm²	Dose mJ/cm ²		
QWO				Type: QWO The QWO is suitable for continuous intense UV irradiation at UV curing applications. It emits a sensor signal that is proportional to the measured UV radiation in the form of a DC 010 V signal. Typically, the QWO is mounted temperature decoupled directly	
UV-A: A001976 UV-B: A002394 UV-C: A001975 UV-Vis: A008133	UV-A oder UV-B oder UV-C oder UV-Vis	mittels DC 0 – 10V		Typically, the QWO is mounted temperature decoupled directly on a UV reflector unit and looks through an opening directly at the UV lamp. Most customers use this sensor in order to detect the lamp ageing, or they use the sensor signal to control the ballast via a machine controller. The purpose is to realise constant UV radiation by adjusting the electrical power of the lamp. Spectral measuring 315 – 395 nm, max. 340 nm ranges: 265 – 325 nm, max. 315 nm 215 – 280 nm, max. 265 nm 380 – 445 nm, max. 405 nm Sensitivity range: 50 – 5,000 mW/cm² Amplification factor: 1, 10, 100, 1000; x 0,3 Max. permissible intensity: 5.000 mW/cm² for max. 10 min Max. permissible temp.: 60° C (cont. operation) External by DC 24V, 5mA Output: Dim./weight sensor: Approx. 45 x 45 x 34 mm / 135 g Special feature: Air purging connection 1/8"	